


SEAGULL 1963 Chronograph Operating Instructions



To set the time: Pull out the crown from position 1 to 2. Rotate the crown until you reach the desired time. Turn hands clockwise only.

To wind: Rotate the crown in the 1 position clockwise until you feel resistance. Then stop. Do not overwind. Wind daily for keeping accurate time. Watch will run about 40 hours on a full wind.

30 minute timer: Click down on pusher A to start the 30 minute stopwatch function. Click down again to stop and measure.

Reset timer: Click down on pusher B to reset the chronograph seconds hand and the 30 minute sub-dial back to zero.

NOTE: ONLY RESET TIMER WHEN STOPPED.

Attempting to reset the timer while it is running will result in damage not covered under warranty. Always stop the timer by clicking pusher A before you reset the stopwatch function.